

# DryCooler & Pump Package Info

Liebert Corporation may make improvements and/or changes in the products described in the document at any time without notice. Part numbers and technical information are subject to change without prior notice.

Liebert Corporation assumes no responsibility and disclaims all liability for incidental or consequential damages resulting for use of this information from errors or omissions.

#### TABLE OF CONTENTS - LIEBERT DIRECT DRIVE DRYCOOLERS

CONTROL TO THE CONTROL OF THE CONTRO
SECTION I - ELECTRICAL PANEL (MODELS "D*O" or "D*G")
ALL
INCLUDES:
CIRCUIT BREAKER
CIRCUIT BREAKER MOUNTING BRACKET
COMPLETE DISCONNECT ASSEMBLY
CONTACTOR
DISCONNECT GASKET
DISCONNECT SWITCH
GROUND LUG
RELAY
THERMOSTAT
TIME DELAY RELAY
TOGGLE SWITCH
TRANSFORMER
SECTION II - ELECTRICAL PANEL (MODELS "D*F")
ALL
INCLUDES:
CAPACITOR
CAPACITOR BOOT
CAPACITOR STRAP
CIRCUIT BREAKER
CIRCUIT BREAKER MOUNTING BRACKET
COMPLETE DISCONNECT ASSEMBLY
CONTACTOR
DISCONNECT GASKET
DISCONNECT SWITCH
FAN SPEED CONTROL
FAN SPEED CONTROL SENSOR
GROUND LUG
THERMOSTAT
TRANSFORMER
VARISTER
SECTION III - FAN MOTOR
ALL
INCLUDES:
FAN MOTOR .
FAN MOTOR MOUNTING ANGLE
FANBLADE
METAL FAN GUARD
SLINGER RING
SECTION IV - COIL
ALL
INCLUDES:
COIL ASSEMBLY

#### TABLE OF CONTENTS - LIEBERT DIRECT DRIVE DRYCOOLERS (Continued)

SECTION V - EXTERIOR PANELS	
ALL	
INCLUDES:	
ELECTRIC BOX COVER	
EXTERIOR END PANEL	
HEADER COVER	
SIDE EXTERIOR PANEL	
TOP EXTERIOR PANEL	
SECTION VI - INSTALLATION KIT	
ALL	
INCLUDES:	
COMPLETE INSTALLATION	KIT
LFG	

#### LIEBERT DIRECT DRIVE DRYCOOLER

SECTION I - ELECTRICAL PANEL (MODELS "D*O" or "D*G")	SEE NOTE 1	
Find No Description   OPTIONAL DISCONNECT SWITCH ASSEMBLY   Disconnect Switch   Disconnect Mounting Bracket   Ground Lug	Part Number 067-1630 E67-0010 F67-0670 E-362B	RSP X
75 VA TRANSFORMER, 200-230 VOLT, 50 HZ	E-330A	x
75 VA TRANSFORMER, 380-415 VOLT, 50 HZ	E-330B	X
75 VA TRANSFORMER, 208-230 VOLT, 60 HZ	E-007A	Х
75 VA TRANSFORMER, 460 VOLT, 60 HZ	E-007B	Х
75 VA TRANSFORMER, 575 VOLT, 60 HZ	E-007C	Х
3.2 AMP CIRCUIT BREAKER	E-276C	Х
CIRCUIT BREAKER MOUNTING BRACKET	1C10102P1	
THERMOSTAT, FAN CYCLING ("D*O") ONLY	E02-0100	X
THERMOSTAT, GLYCOOL CHILLERS ("D*G") ONLY	E-0350	х
25/30 AMP CONTACTOR, FAN, 1 FAN ("D*O" ONLY)	E-0110	Х
30/40 AMP CONTACTOR, FAN, 2/3/4 FAN ("D*O" ONLY)	E-009F	X
25/30 AMP CONTACTOR, PUMP	E-0110	х
2P/2T RELAY, DUAL PUMP PACKAGE ONLY	E-0130	X
TIME DELAY RELAY, DUAL PUMP PACKAGE ONLY	E-3530	Х
TOGGLE SWITCH, DUAL PUMP PACKAGE ONLY	E-3490	Х
***REFER TO APPENDIX F FOR FUSE & FUSEBLOCK SELEC	TIONS***	

#### NOTES:

1.) Do not use this section for drycooler models with a "DN\*" prefix.

#### LIEBERT DIRECT DRIVE DRYCOOLER (Continued)

SECTION II - ELECTRICAL PANEL (MODELS "D*F")	SEE NOTE 1	
Find No Description  OPTIONAL DISCONNECT SWITCH ASSEMBLY Disconnect Switch Disconnect Mounting Bracket Ground Lug	Part Number 067-1630 E67-0010 F67-0670 E-362B	RSP X
75 VA TRANSFORMER, 200-230 VOLT, 50 HZ	E-330A	. X
75 VA TRANSFORMER, 380-415 VOLT, 50 HZ	E-330B	х
75 VA TRANSFORMER, 208-230 VOLT, 60 HZ	E-007A	х
75 VA TRANSFORMER, 460 VOLT, 60 HZ	E-007B	Х
75 VA TRANSFORMER, 575 VOLT, 60 HZ	E-007C	х
1.5 KVA TRANSFORMER, 460 VOLT, 60 HZ ONLY	E-0010	Х
1.5 KVA TRANSFORMER, 575 VOLT, 60 HZ ONLY	E-0020	Х
3.2 AMP CIRCUIT BREAKER	E-276C	Х
CIRCUIT BREAKER MOUNTING BRACKET	F02-4380	
20/30 AMP CONTACTOR, FAN & PUMP	E-011A	x
FAN SPEED CONTROL (F.S.C.)	E-325A	х
FAN SPEED CONTROL SENSOR	E-325B	x
20 MFD CAPACITOR	B-095B	х
CAPACITOR BOOT	B-1450	
CAPACITOR STRAP	S67-0010	
VARISTER	G-200B	х
***REFER TO APPENDIX F FOR FUSE & FUSEBLOCK SI	ELECTIONS***	

#### NOTES

1.) Do not use this section for drycooler models with a "DN\*" prefix.

#### LIEBERT DIRECT DRIVE DRYCOOLER (Continued)

SECTION III - FAN MOTOR		
Find No Description	Part Number	RSP
.75 H.P. FAN SPEED CONTROL MOTOR	B-095C	X
.75 H.P. CONSTANT SPEED FAN MOTOR, 200-460 VOL	ET B67-0010	x
.75 H.P. CONSTANT SPEED FAN MOTOR, 575 VOLT	1C16992P1	X
SLINGER RING (RAIN GUARD), FAN SPEED MOTOR	D-1830	X
FAN MOTOR MOUNTING ANGLE	F69-0270	
FANBLADE	D67-003A	Х
METAL FAN GUARD	D67-003B	

SECTION IV - COIL								
Find No Description	Part Number	RSP						
COIL ASSEMBLY, D** 069, 8 CIRCUITS	1D10088G1							
COIL ASSEMBLY, D** 092, 12 CIRCUITS	1D10092G1							
COIL ASSEMBLY, D** 109, 16 CIRCUITS	1D10090G1							
COIL ASSEMBLY, D** 112, 16 CIRCUITS	1D10095G1							
COIL ASSEMBLY, D** 139, 16 CIRCUITS	1D10089G1							
COIL ASSEMBLY, D** 174, 16 CIRCUITS	1D10093G1							
COIL ASSEMBLY, D** 225, 26 CIRCUITS	1D10096G1							
COIL ASSEMBLY, D** 260, 24 CIRCUITS	1D10094G1							
COIL ASSEMBLY, D** 310, 32 CIRCUITS	1D10091G1							
COIL ASSEMBLY, D** 350, 32 CIRCUITS	1D10097G1							
COIL ASSEMBLY, D** 352, 24 CIRCUITS	1D13283G1							
COIL ASSEMBLY, D** 419, 32 CIRCUITS	1D13284G1							
COIL ASSEMBLY, D** 466, 40 CIRCUITS	1D13279G1							
COIL ASSEMBLY, D** 491, 48 CIRCUITS	1D13280G1							

#### LIEBERT DIRECT DRIVE DRYCOOLER (Continued)

SECTION V - EXTERIOR PANELS							
Find No		Part Number	RSP				
•	TOP PANEL, FAN 1 (ALSO COVERS TOP OF ELECTRIC BOX)	F67-0140					
   	TOP PANEL, AUXILLARY FAN (ONE PER AUXILLARY FAN)	1D13454P1					
 	ELECTRIC BOX COVER	F67-0300					
! ! !	HEADER COVER	F67-0310					
; [	END PANEL	F67-0260					
   	RIGHT SIDE PANEL, 1 FAN	F67-0180					
   	LEFT SIDE PANEL, 1 FAN	F67-0190					
	RIGHT SIDE PANEL, 2 FAN	F67-0200					
	LEFT SIDE PANEL, 2 FAN	F67-0210					
! [	RIGHT SIDE PANEL, 3 FAN	F67-0220					
1   	LEFT SIDE PANEL, 3 FAN	F67-0230					
	RIGHT FRONT SIDE PANEL, 4 FAN	F67-0200					
   	LEFT FRONT SIDE PANEL, 4 FAN	F67-0210					
	RIGHT REAR SIDE PANEL, 4 FAN	1D13452P1					
	LEFT REAR SIDE PANEL, 4 FAN	1D13453P1					

	SECTION VI - INSTALLA	TION KITS
Find No	Description	Part Number RSP
1	INSTALLATION KIT, 1/2/3 FAN	067-0260
	Leg (4 Supplied)	F67-0440
	INSTALLATION KIT, 4 FAN	067–6160
1	Leg (6 Supplied)	F67-0440

APPENDIX F

LIEBERT DIRECT DRIVE DRYCOOLER FUSE & FUSEBLOCK SELECTIONS

VOLT	HERTZ	F.S.C	FAN SPEED MOTOR		S.C   FAN SPEED MOTOR   LINE VOLTAGE			TAGE
			AMP	FUSE	FUSEBLOCK	AMP	FUSE	FUSEBLOCK
200	50	YES		N/A		30.0	E-2090	E-6040
208	60	YES		N/A	1	30.0	E-2090	E-6040
230	50	YES		N/A		30.0	E-2090	E-6040
230_	60	YES	l	N/A		30.0	E-2090	E-6040
460	60	YES	4.0	E-2860	E-1030	15.0	E-2410	E-1060
575	60	YES	3.2	E-1960	E-1030	15.0	E-2410	E-1060
200	50	NO		N/A		15.0	E-2070	E-1020
208	60	NO		N/A		15.0	E-2070	E-1020
230	50	NO		N/A		15.0	E-2070	E-1020
_230	60	NO		N/A		15.0	E-2070	E-1020
400	50	NO		N/A		15.0	E-2410	E-1050
<b>4</b> 60	60	NO		N/A		15.0	E-2410	E-1050
575	60	NO		N/A		15.0	E-2410	E-1050

#### NOTES:

1.) All models supplied with Diaz type fuses are supplied with the following protection devices for the line voltage:

E-202A FUSE

E-202B FUSE ADAPTER

E-362A FUSE BASE

E-3640 FUSE CAP

These units are not supplied with any protection devices for the Fan  $\mbox{\it Speed}$  Control motor.

#### APPENDIX G

#### DIRECT DRIVE DRYCOOLER MODEL SELECTIONS ACCOMMODATE II/CHALLENGER II/FS-US

MODEL NUMBER	HZ	AMBIENT 1	AMBIENT 2	AMBIENT 3	AMBIENT 4	AMBIENT 5
AU 24G/L	50	N/A	D15-0020*	N/A	N/A	N/A
AU 25G/L	60	N/A	N/A	D15-0020*	N/A	N/A
CU/CF 41G	50	DSF-069	DSF-069	N/A	N/A	N/A
CU/CF 41G	60	N/A	N/A	DSF-092	N/A	N/A
CU/CF 60G	50	DSF-069	DSF-069	N/A	N/A	N/A
CU/CF 60G	60	N/A	N/A	DSF-109	N/A	DSF-108
FS/US 39G	50	D**-069	D**-069	D**-069	D**-069	N/A
FS/US 39G	60	N/A	N/A	D**-069	D**-069	D**-069
FS/US 62G	50	D**-069	D**-069	D**-069	D**-092	N/A
FS/US 62G	60	N/A	N/A	D**-092	D**-092	D**-112

<sup>\*</sup> Drycooler D15-0020 is not manufactured by Liebert. Refer to APPENDIX for control box selection.

#### AMBIENT 1

85°F (29.4°C) @ Less Than 5,000 Ft. (1,524 M) Above Sea Level

#### AMBIENT 2

 $90^{\rm O}{\rm F}$  (32.2°C) @ Less Than 5,000 Ft. (1,524 M) Above Sea Level -OR-

85°F (29.4°C)5 @ More Than 5,000 Ft. (1,524 M) Above Sea Level

#### AMBIENT 3

 $95^{\rm OF}$  (35.0°C) @ Less Than 5,000 Ft. (1,524 M) Above Sea Level -OR-

90°F (32.2°C) @ More Than 5,000 Ft. (1,524 M) Above Sea Level

#### AMBIENT 4

 $100^{\mathrm{OF}}$  (37.8°C) @ Less Than 5,000 Ft. (1,524 M) Above Sea Level -OR-

95°F (35.0°C @ More Than 5,000 Ft. (1,524 M) Above Sea Level

#### AMBIENT 5

 $105^{\rm O}{\rm F}$  (40.1°C) @ Less Than 5,000 Ft. (1,524 M) Above Sea Level -OR-

100°F (37.8°C) @ More Than 5,000 Ft. (1,524 M) Above Sea Level

#### APPENDIX G (Continued)

### DIRECT DRIVE DRYCOOLER MODEL SELECTIONS (Continued) SYSTEM/3 & CHILLER SERIES 3000

MODEL NUMBER         HZ         AMBIENT 1         AMBIENT 2         AMBIENT 3         AMBIENT 4         AMBIENT 5           FH/UH 72G         50         D**-092         D**-109         D**-139         D**-225         N/A           FH/UH 72G         60         N/A         N/A         D**-112         D**-139         D**-139         D**-22           FH/UH 110G         50         D**-112         D**-139         D**-174         D**-260         N/A	 5
FH/UH 110G   50   D**-112   D**-139   D**-174   D**-260   N/A	
FH/UH 110G   50   D**-112   D**-139   D**-174   D**-260   N/A	
THE /THE 110C I CO I ST/R I ST/R	0
FH/UH 110G   60   N/A   N/A   D**-174   D**-225   D**-35	i
FH/UH 116G   50   D**-174   D**-174   D**-225   D**-310   N/A	
FH/UH 116G   60   N/A   N/A   D**-174   D**-260   D**-35	0 1
FH/UH 192G   50   D**-174   D**-225   D**-260   D**-352   N/A	1
FH/UH 192G   60   N/A   N/A   D**-260   D**-350   D**-41	9 1
FH/UH 240G   50   D**-225   D**-260   D**-350   N/A	
FH/UH 240G   60   N/A   N/A   D**-310   D**-350   D**-46	6 1
FH/UH 265G   50   D**-260   D**-260   D**-350   D**-466   N/A	1
FH/UH 265G   60   N/A   N/A   D**-350   D**-466   N/A	1
AS-53G   50   D**-069   D**-069   D**-069   N/A	i
AS-63G   60   N/A   N/A   D**-069   D**-069   D**-06	9 1
AS-89G   50   D**-069   D**-092   D**-092   N/A	1
AS-103G   60   N/A   N/A   D**-092   D**-11	2 1
AS-167G   50   D**-092   D**-112   D**-139   D**-174   N/A	1
AS-169G   60   N/A   N/A   D**-109   D**-112   D**-13	9
AS-203G   60   N/A   N/A   D**-139   D**-174   D**-175	
AS-211G   50   D**-139   D**-174   D**-174   D**-260   N/A	
AS-251G   60   N/A   N/A   D**-225   D**-260   D**-31	0 1
CS-27G   50   D**-069   D**-069   D**-069   N/A	
CS-32G   60   N/A   N/A   D**-069   D**-069   D**-069	9 1
CS-45G   50   D**-069   D**-092   D**-092   N/A	1
CS-52G   60   N/A   N/A   D**-092   D**-011	2
CS-84G   50   D**-092   D**-112   D**-139   D**-174   N/A	1
CS-85G   60   N/A   N/A   D**-109   D**-112   D**-139	9 1
CS-102G   60   N/A   N/A   D**-139   D**-174   D**-175	
CS-106G   50   D**-139   D**-174   D**-174   D**-260   N/A	
CS-126G   60   N/A   N/A   D**-225   D**-260   D**-310	0 1
$CD-54G^{**}$   50   $D^{**}-069$   $D^{**}-069$   $D^{**}-069$   $D^{**}-069$   $D^{**}-069$   $D^{**}$	<del>-  </del>
CD-64G**   60   N/A   N/A   D**-069   D**-069	9 1
CD-90G**   50   D**-069   D**-069   D**-092   D**-092   N/A	1
CD-104G**   60   N/A   N/A   D**-092   D**-092   D**-119	2 1
CD-168G**   50   D**-092   D**-112   D**-1309   D**-174   N/A	<del>- i</del>
CD-170G**   60   N/A   N/A   D**-109   D**-112   D**-130	<del>-  </del>
CD-204G**   60   N/A   N/A   D**-139   D**-174   D**-174	
CD-212G**   50   D**-139   D**-174   D**-174   D**-260   N/A	<del>-  </del>
CD-252G**   60   N/A   N/A   D**-225   D**-260   D**-310	5 1

<sup>\*</sup> REFER TO PREVIOUS PAGE FOR AMBIENT DESCRIPTIONS

<sup>\*\*</sup> MODELS WITH A "CD" PREFIX REQUIRE TWO(2) DRYCOOLERS PER UNIT

### APPENDIX A (Continued) MODEL NUMBER BREAKDOWNS

#### LIEBERT DIRECT DRIVE DRYCOOLERS

DISCONNECT SWITCH DESIGNATION	.ow) is in this lisconnect 'AGE TYPE of	_	C 1 :	L 2 1	A 2	6 D
locking disconnect.			<b>!</b>			1
DRYCOOLER DESIGNATION						
TYPE OF PUMP PACKAGE D - Dual N - None S - Single						
CONTROL CODE C - No Control F - Fan Speed Control with Pump G - Standard GLYCOOL Chiller Series L - Main Control (Single Contactor; T - Fan Cycling Control (Thermostat O - Fan Cycling Control with Pump (S S - Special Control	No Pumps) Controlled:	No Pumr	) () () () () () () () () () () () () ()			
092 (1 Fan; 12 Circuits)       310         109 (1 Fan; 16 Circuits)       350         112 (1 Fan; 16 Circuits)       352         139 (2 Fan; 16 Circuits)       419         174 (2 Fan; 16 Circuits)       466	(3 Fan; 24 (3 Fan; 32 (3 Fan; 32 (4 Fan; 24 (4 Fan; 32 (4 Fan; 40 (4 Fan; 48	Circuit Circuit Circuit Circuit	(S) (S) (S) (S) (S)			
VOLTAGE	/60					
(see CAPACITY above) the special number will be designated in this position.	en the star per of circu	naard lits				
DIAZ FUSE DESIGNATION						

### PIGGYBACK DRYCOOLER (Continued) PD\*102/PD\*133/PD\*150 (Continued)

	SECTION IV - COIL	
Find No	Description	Part Number RSP
ļ	COIL, PD*102	X02-002S
	COIL, PD*133 & PD*150	X02-003S
	COIL DRAIN PAN	F20-2460

	SECTION V - PIPING		
Find No	Description	Part Number	RSP
	1.5 H.P. PUMP, 208-460 VOLT	P-281A	X
 	1.5 H.P. PUMP, <b>575 VOLT</b>	P-281B	X
	2.0 H.P. PUMP, 208-460 VOLT	P-381B	Х
1	2.0 H.P. PUMP, 575 VOLT	P-381C	Х
i t i	3.0 H.P. PUMP, 208-460 VOLT	P-296A	X
i !	3.0 H.P. PUMP, <b>575 VOLT</b>	P-296B	X
	3-WAY VALVE, PD*102 & PD*133	P-3600	X
 	3-WAY VALVE, PD*150	P-4390	X
} ! !	EXPANSION TANK	P-2840	Х
! !	GATE VALVE, PD*102 & PD*133 WITH PUMP(S)	P07-0080	
]	GATE VALVE, PD*150 WITH PUMP(S)	P07-0110	ļ
	CHECK VALVE, DUAL PUMPS ONLY	P-411D	
<u>.</u>	FLOW SWITCH, DUAL PUMPS ONLY	P-4120	
	MODULATING MOTOR ASSEMBLY, NO PUMPS or DUAL PUMPS Modulating Motor Linkage Wire Harness	026-0026 M-0010 M-0050 022-3295	X   X
	MODULATING MOTOR ASSEMBLY, SINGLE PUMP Modulating Motor Linkage Wire Harness	1C14124G1 M-0010 M-0050 1C14114G1	Х

#### TABLE OF CONTENTS - PIGGYBACK DRYCOOLERS (Continued)

SECTION IV -	COIL
	PB210G1
	PD*102/PD*133/PD*1506
	PD*223/PD*290/PD*33311
	INCLUDES:
	COIL
	COIL DRAIN PAN
SECTION V - F	PIPING
	PB210G2
	PD*102/PD*133/PD*1506
	PD*223/PD*290/PD*33311
	INCLUDES:
	3-WAY VALVE
	CHECK VALVE
	COMPLETE MODULATING MOTOR ASSEMBLY
	EXPANSION TANK
	FLOW SWITCH
	GATE VALVE
	LINKAGE
	MODULATING MOTOR
	PUMP
	RELIEF VALVE
	WIRE HARNESS (FOR MODULATING MOTOR ASSEMBLY)
SECTION VI -	EXTERIOR PANELS
OBOTION VI	PB210G2
	PD*102/PD*133/PD*150
	PD*223/PD*290/PD*33312
	INCLUDES:
	ALUMINUM TRIM
	COMPLETE EXTERIOR PANEL ASSEMBLY
	DISCONNECT SWITCH BEZEL
	DZUS FASTENER PART
	FRONT EXTERIOR PANEL
	LIEBERT NAMEPLATE
	SIDE EXTERIOR PANEL
	TOP COVER
SECTION VII -	- FILTER
	PD*102/PD*133/PD*1507
	PD*223/PD*290/PD*33312
	INCLUDES:
	FILTER

### PIGGYBACK DRYCOOLER (Continued) PD\*223/PD\*290/PD\*333 (Continued)

	SECTION IV - COIL	
Find No	Description COIL, PD*223	Part Number RSP
1	COIL, PD-223	X02-004S
	COIL, PD*290 & PD*333	X02-006S
İ	COIL DRAIN PAN	F20-2470

!	SECTION V - PIPING		
Find No	Description	Part Number	RSP
	3.0 H.P. PUMP, <b>208-460 VOLT</b>	P-296A	X
	3.0 H.P. PUMP, <b>575 VOLT</b>	P-296B	Х
	5.0 H.P. PUMP, 208-460 VOLT	P02-001A	Σ
	5.0 H.P. PUMP, <b>575 VOLT</b>	P02-001B	X
	3-WAY VALVE	P-4390	Х
	EXPANSION TANK	P-2840	X
	GATE VALVE	P07-0110	
	CHECK VALVE, DUAL PUMPS ONLY	P-4110	
	FLOW SWITCH, DUAL PUMPS ONLY	P-4120	
	MODULATING MOTOR ASSEMBLY, NO PUMPS or DUAL PUMPS Modulating Motor Linkage Wire Harness	026-0026 M-0010 M-0050 022-3295	
	MODULATING MOTOR ASSEMBLY, SINGLE PUMP Modulating Motor	1C14124G1 M-0010	X
	Linkage Wire Harness	M-0050 1C14114G1	Х

#### PUMP PACKAGES FOR LIEBERT DRYCOOLERS

#### THIS SECTION IS SUPPORTED BY THE INDEX AND THE FOLLOWING APPENDIXES:

APPENDIX A - MODEL NUMBER BREAKDOWN APPENDIX G - SELECTION CHART

#### TABLE OF CONTENTS

SECTION I - SINGLE PUMP PACKAGE
CHALLENGER II/SYSTEM III/GLYCOL CHILLERS
.75 H.P1
1.0 H.P1
1.5 H.P2
2.0 H.P3
3.0 H.P5
5.0 H.P7
GLYCOOL CHILLERS
ALL15
INCLUDES:
3-WAY VALVE
COMPLETE SINGLE PUMP PACKAGE
COMPRESSION TANK
COVER
EXPANSION TANK
FUSE
HEATER
HEATER & FUSE KIT
INSTRUCTIONS (FOR HEATER & FUSE KIT)
LINKAGE
MODULATING MOTOR
PUMP
PUMP PACKAGE MOUNTING ANGLE
RELIEF VALVE
SINGLE PUMP BASE
SINGLE PUMP HOUSING
SINGLE PUMP PACKAGE
WRAPPER

#### TABLE OF CONTENTS (Continued)

ECTION II - DUAL PUMP PACKAGE
CHALLENGER II/SYSTEM III/GLYCOL CHILLERS
.75 H.P8
1.0 H.P8
1.5 H.P9
2.0 H.P10
3.0 H.P12
5.0 H.P14
INCLUDES:
COMPLETE DUAL PUMP PACKAGE
COVER
DUAL PUMP BASE
DUAL PUMP HOUSING
DUAL PUMP PACKAGE
EXPANSION TANK
FLOW SWITCH
FUSE
HEATER
HEATER & FUSE KIT
INSTRUCTIONS (FOR HEATER & FUSE KIT)
PUMP PACKAGE MOUNTING ANGLE
WRAPPER

### GLYCOL PUMP PACKAGE FOR LIEBERT DRYCOOLERS CHALLENGER II/SYSTEM III/GLYCOL CHILLERS

	SECTION I - SINGLE PUMP PACKAGE		
Find No	Description	Part Number	RSP
LTIM NO	COMPLETE SINGLE PUMP PACKAGE, .75 H.P., 208/1/60		
	Expansion Tark	P-2840	
	.75 H.P., Single Pump Package	1D10153G3	
	.75 H.P. Pump	P13-0030	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-2350	)
	Cover	F20-2360	)
	Cover Pump Package Mounting Angle (2 Supplied)	F20-2370	
	Single Pump Base	F20-2440	
	orinare ramb base		
	COMPLETE SINGLE PUMP PACKAGE, .75 H.P., 200/1/50	S 3/4W	
	Expansion Tank	P-2840	
	.75 H.P., Single Pump Package	1D10153G4	
	.75 H.P. Pump	P13-0060	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-2350	)
	Cover	F20-2360	)
	Pump Package Mounting Angle (2 Supplied)	F20-2370	)
	Single Pump Base	F20-2440	)
	COMPLETE SINGLE PUMP PACKAGE, 1.0 H.P., 380/3/50	S 1M	
	Expansion Tank	P-2840	
	1.0 H.P., Single Pump Package	1D10153G5	
	1.0 H.P. Pump	P-280B	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-2350	
	Cover	F 20-230	
• •	Pump Package Mounting Angle (2 Supplied)	F20-237	
	Single Pump Base	F20-244	O
	Heater & Fuse Kit	1C11288G13	
i	E-32 Heater (3 Supplied)	E-0860	
•	15.0 Amp Fuse (3 Supplied)	E-2410	Х
	Instructions (For Heater & Fuse Kit)	1A11252P1	X
1		) C 13T	
	COMPLETE SINGLE PUMP PACKAGE, 1.0 H.P., 200/3/50	) S 1N	
1	Expansion Tank	P-2840	
	1.0 H.P., Single Pump Package	1D10153G5	₹:
	1.0 H.P. Pump	P-280B	. X
	Single Pump Housing	1D10118G8	
1	Wrapper (One Half of Housing) 2 Supplied	F20-235	
	Cover	F20-236	
1	Pump Package Mounting Angle (2 Supplied)	F20-237 F20-244	
	Single Pump Base		·
1	Heater & Fuse Kit	1C11288G15	•
•	E-44 Heater (3 Supplied)	E-0910 E-2070	<u>}</u>
1	15.0 Amp Fuse (3 Supplied) Instructions (For Heater & Fuse Kit)	E-2070 1A11252P1	

1	SECTION I - SINGLE PUMP PACKAGE (Continue	ed)	
Find %o	Description	Part Number	RSP
	COMPLETE SINGLE PUMP PACKAGE, 1.5 H.P., 460/3/60	S 1.5A	
1	Expansion Tank	P-2840	
l	1.5 H.P., Single Pump Package	1D10153G8	
	1.5 H.P. Pump	P-281A	X
	Single Pump Housing	1D10118G8	3
[	Wrapper (One Half of Housing) 2 Supplied	F20-235	50
	Cover	F20-236	50
	Pump Package Mounting Angle (2 Supplied)	F20-237	70
	Single Pump Base	F20-244	
İ	Heater & Fuse Kit	1C11288G3	
l i	E-34 Heater (3 Supplied)	E-2610	X
	15.0 Amp Fuse (3 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	X
	COMPLETE SINGLE PUMP PACKAGE, 1.5 H.P., 575/3/60	S 1.5B	
	Expansion Tank	P-2840	
	1.5 H.P., Single Pump Package	1D10153G9	
	1.5 H.P. Pump	P-281B	X
	Single Pump Housing	1D10118G8	3
	Wrapper (One Half of Housing) 2 Supplied		
	Cover	F20-236	
	Pump Package Mounting Angle (2 Supplied)	F20-237	
	Single Pump Base	F20-244	
	Heater & Fuse Kit	1C11288G5	
	E-29 Heater (3 Supplied)	E-1840	X
	15.0 Amp Fuse (3 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	
	COMPLETE SINGLE PUMP PACKAGE, 1.5 H.P., 380/3/50	S 1.5M	
	Expansion Tank	P-2840	
	1.5 H.P., Single Pump Package	1D10153G7	
	1.5 H.P. Pump	P-280A	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-235	
	Cover	F20-236	
	Pump Package Mounting Angle (2 Supplied)	F20-237	
	Single Pump Base	F20-244	
	Heater & Fuse Kit	1C11288G24	
	E-37 Heater (3 Supplied)	E-0870	X
	15.0 Amp Fuse (3 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	

SECTION I - SINGLE PUMP PACKAGE (Conti	.nued)
  Find No Description	Part Number RSP
COMPLETE SINGLE PUMP PACKAGE, 1.5 H.P., 200/3/	
Expansion Tank	P-2840
1.5 H.P., Single Pump Package	1D10153G10
1.5 H.P. Pump	P-5070 X
Single Pump Housing	1D10118G8
Wrapper (One Half of Housing) 2 Supplied	F20-2350
Cover	F20-2360
Pump Package Mounting Angle (2 Supplied)	F20-2370
Single Pump Base	F20-2440
Heater & Fuse Kit	1C11288G4
E-48 Heater (3 Supplied)	E-0940 X
15.0 Amp Fuse (3 Supplied)	E-2070 X
Instructions (For Heater & Fuse Kit)	1A11252P1 X
COMPLETE SINGLE PUMP PACKAGE, 1.5 H.P., 208/3/	′60 S 1.5Y
Expansion Tank	P-2840
1.5 H.P., Single Pump Package	1D10153G8
1.5 H.P. Pump	P-281A X
Single Pump Housing	1D10118G8
Wrapper (One Half of Housing) 2 Supplied	F20-2350
Cover	F20-2360
Pump Package Mounting Angle (2 Supplied)	F20-2370
Single Pump Base	F20-2440
Heater & Fuse Kit	1C11288G1
E-44 Heater (3 Supplied)	E-0910 X
15.0 Amp Fuse (3 Supplied)	E-2070 X
Instructions (For Heater & Fuse Kit)	1A11252P1 X
COMPLETE SINGLE PUMP PACKAGE, 2.0 H.P., 460/3/	
Expansion Tank	P-2840
2.0 H.P., Single Pump Package	1D10153G12
2.0 H.P. Pump	P-381B X
Single Pump Housing	1D10118G8
Wrapper (One Half of Housing) 2 Supplied	F20-2350
Cover	F20-2360
Pump Package Mounting Angle (2 Supplied)	F20-2370
Single Pump Base	F20-2440
Heater & Fuse Kit	1C11288G2
E-38 Heater (3 Supplied)	E-0860 X
15.0 Amp Fuse (3 Supplied)	E-2410 X
Instructions (For Heater & Fuse Kit)	1A11252P1 X

-	SECTION I - SINGLE PUMP PACKAGE (Continue	ed)	
Find No		Part Number	RSP
1	COMPLETE SINGLE PUMP PACKAGE, 2.0 H.P., 575/3/60	S 2B	
1	Expansion Tank	P-2840	
1	2.0 H.P., Single Pump Package	1D10153G13	
1	2.0 H.P. Pump	P-381C	X
1	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied Cover	F20-235 F20-236	
!	Pump Package Mounting Angle (2 Supplied)		
! !	Single Pump Base	F20-244	
; {	Heater & Fuse Kit	1C11288G3	.0
i i	E-34 Heater (3 Supplied)		X
i t	15.0 Amp Fuse (3 Supplied)	E-2610	
! :	Instructions (For Heater & Fuse Kit)	E-2410	
1	instructions (for heater & fuse kit)	1 <b>A</b> 11252P1	. X
į	COMPLETE SINGLE PUMP PACKAGE, 2.0 H.P., 380/3/50		
	Expansion Tank	P-2840	
1	2.0 H.P., Single Pump Package	1D10153G11	
1	2.0 H.P. Pump	P-282A	
	Single Pump Housing	1D10118G8	i
	Wrapper (One Half of Housing) 2 Supplied Cover		
i :		F20-236	
	Pump Package Mounting Angle (2 Supplied) Single Pump Base		
	Heater & Fuse Kit	F20-244	U
	E-41 Heater (3 Supplied)	1C11288G7	7.7
<b>:</b> <b>!</b>		E-2660	
i !	15.0 Amp Fuse (3 Supplied)	E-2410	
¦ 	Instructions (For Heater & Fuse Kit)	1 <b>A</b> 11252P1	Х
	COMPLETE SINGLE PUMP PACKAGE, 2.0 H.P., 200/3/50		
	Expansion Tank	P-2840	
	2.0 H.P., Single Pump Package	1D10153G14	
	2.0 H.P. Pump	P-5080	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-235	0
	Cover	F20-236	0
	Pump Package Mounting Angle (2 Supplied)	F20-237	0
	Single Pump Base	F20-244	0
	Heater & Fuse Kit	1C11288G9	
	E-52 Heater (3 Supplied)	E-0960	X
	15.0 Amp Fuse (3 Supplied)	E-2070	Х
L	Instructions (For Heater & Fuse Kit)	1A11252P1	

[	SECTION I - SINGLE PUMP PACKAGE (Continu	ed)	************
Find No		Part Number	RSP
1	COMPLETE SINGLE PUMP PACKAGE, 2.0 H.P., 208/3/60	S 2Y	
1	Expansion Tank	P-2840	
1	2.0 H.P., Single Pump Package	1D10153G12	
1	2.0 H.P. Pump	P-381B	X
!	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied Cover	F20-235 F20-236	
	Pump Package Mounting Angle (2 Supplied)	F20-237	0
	Single Pump Base	F20-244	
•	Heater & Fuse Kit	1C11288G6	
[	E-49 Heater (3 Supplied)	E-1810	Х
	15.0 Amp Fuse (3 Supplied)	E-2070	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	X
	COMPLETE SINGLE PUMP PACKAGE, 3.0 H.P., 460/3/60		
	Expansion Tank	P-2840	
İ	3.0 H.P., Single Pump Package	1D10153G16	
	3.0 H.P. Pump	P-296A	
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied Cover	F20-235 F20-236	
j	Pump Package Mounting Angle (2 Supplied)	F20-237	0
f 1	Single Pump Base	F20-244	0
!	Heater & Fuse Kit	1C11288G7	
1	E-41 Heater (3 Supplied)	E-2660	X
	15.0 Amp Fuse (3 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1 <b>A</b> 11252P1	
	COMPLETE SINGLE PUMP PACKAGE, 3.0 H.P., 575/3/60		
!	Expansion Tank	P-2840	
	3.0 H.P., Single Pump Package	1D10153G17	
	3.0 H.P. Pump	P-296B	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-235	
	Cover	F20-236	
	Pump Package Mounting Angle (2 Supplied)	F20-237	
	Single Pump Base	F20-244	0
	Heater & Fuse Kit	1C11288G2	
1	E-38 Heater (3 Supplied)	E-0880	X
1	15.0 Amp Fuse (3 Supplied)	E-2410	X
<u> </u>	Instructions (For Heater & Fuse Kit)	1A11252P1	X

	SECTION I - SINGLE PUMP PACKAGE (Continue	ed)	
Find No		Part Number	RSP
	COMPLETE SINGLE PUMP PACKAGE, 3.0 H.P., 380/3/50	S 3M	
	Expansion Tank	P-2840	
	3.0 H.P., Single Pump Package	1D10153G15	
	3.0 H.P. Pump	P-285A	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-235	0
	Cover	F20-236	0
! !	Pump Package Mounting Angle (2 Supplied)	F20-237	0
	Single Pump Base	F20-244	0
	Heater & Fuse Kit	1C11288G7	
	E-44 Heater (3 Supplied)	E-0910	X
	15.0 Amp Fuse (3 Supplied)	E-2410	Х
	Instructions (For Heater & Fuse Kit)	1A11252P1	X
	COMPLETE SINGLE PUMP PACKAGE, 3.0 H.P., 200/3/50	S 3N	
	Expansion Tank	P-2840	
	3.0 H.P., Single Pump Package	1D10153G18	
	3.0 H.P. Pump	P-5090	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-235	0
	Cover	F20-236	0
	Pump Package Mounting Angle (2 Supplied)	F20-237	0
	Single Pump Base	F20-244	0
	Heater & Fuse Kit	1C11288G11	
! i	E-53 Heater (3 Supplied)	E-0970	X
	15.0 Amp Fuse (3 Supplied)	E-2070	X
! !	Instructions (For Heater & Fuse Kit)	1A11252P1	X
	COMPLETE SINGLE PUMP PACKAGE, 3.0 H.P., 208/3/60		
	Expansion Tank	P-2840	
	3.0 H.P., Single Pump Package	1D10153G16	
	3.0 H.P. Pump	P-296A	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-235	0
	Cover	F20-236	0
	Pump Package Mounting Angle (2 Supplied)	F20-237	0
	Single Pump Base	F20-244	0
	Heater & Fuse Kit	1C11288G8	
	E-52 Heater (3 Supplied)	E-0960	Х
	15.0 Amp Fuse (3 Supplied)	E-2070	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	

SECTION I - SINGLE PUMP PACKAGE (Continue	ed)	1
	Part Number	RSP
COMPLETE SINGLE PUMP PACKAGE, 5.0 H.P., 460/3/60	S 5A	
Expansion Tank	P-2840	
5.0 H.P., Single Pump Package	1D10153G19	
5.0 H.P. Pump	P02-001A	X
Single Pump Housing	1D10118G4	
Wrapper (One Half of Housing) 2 Supplied Cover	F20-235 F20-236	
1		
Pump Package Mounting Angle (2 Supplied)	F20-231 F20-244	
Single Pump Base		
Heater & Fuse Kit	1C11288G14	
E-51 Heater (3 Supplied)	E-0950	
15.0 Amp Fuse (3 Supplied)	E-2410	
Instructions (For Heater & Fuse Kit)	1A11252P1	Х
COMPLETE SINGLE PUMP PACKAGE, 5.0 H.P., 575/3/60		
Expansion Tank	P-2840	
5.0 H.P., Single Pump Package	1D10153G20	
5.0 H.P. Pump	P02-001B	
Single Pump Housing	1D10118G4	
Wrapper (One Half of Housing) 2 Supplied Cover	F20-235 F20-236	
Pump Package Mounting Angle (2 Supplied)	F20-237	0
Single Pump Base	F20-244	
Heater & Fuse Kit	1C11288G16	
E-47 Heater (3 Supplied)	E-0930	
15.0 Amp Fuse (3 Supplied)	E-2410	
Instructions (For Heater & Fuse Kit)	1A11252P1	
COMPLETE CINCLE DIME DACKACE FO LLD COC (0 (CC	C EV	
COMPLETE SINGLE PUMP PACKAGE, 5.0 H.P., 208/3/60		
Expansion Tank	P-2840	
5.0 H.P., Single Pump Package	1D10153G19	
5.0 H.P. Pump	P02-001A	
Single Pump Housing	1D10118G4	
Wrapper (One Half of Housing) 2 Supplied	F20-235	
Cover	F20-236	
Pump Package Mounting Angle (2 Supplied)	F20-237	
Single Pump Base	F20-244	.O.
Heater & Fuse Kit	1C11288G12	
E-60 Heater (3 Supplied)	E-2670	X
25.0 Amp Fuse (3 Supplied)	E-2080	X
Instructions (For Heater & Fuse Kit)	1A11252P1	<u> </u>

	SECTION II - DUAL PUMP PACKAGE	······································	
Find No Desc	ription	Part Number	RSP
	L PUMP PACKAGE, .75 H.P., 208/1/60	D .75P	
Expansion		P-2840	
Flow Switc	h	P-4620	X
.75 H.P.,	Dual Pump Package	018-0714	
.75 H.P.	Pump (2 Supplied)	P13-0030	Х
Dual Pum	p Housing	1D10118G6	3
Wrappe	er (One Half of Housing) 2 Supplied	F20-239	90
Cover		F20-240	00
Pump P	ackage Mounting Angle (2 Supplied)	F20-237	70
Dual P	rump Base	F20-243	30
15.0 Amp F	use (4 Supplied)	E-2070	Х
Instruction	ns (For Fuse Installation)	1A11252P1	X
1			
COMPLETE DUA	L PUMP PACKAGE, 1.0 H.P., 380/3/50	D 1M	
Expansion	Tank	P-2840	
Flow Switc	h .	P-4620	X
1.0 H.P.,	Dual Pump Package	1D10153G23	
1.0 H.P.	Pump (2 Supplied)	P-280B	X
Dual Pum	p Housing	1D10118G6	5
Wrappe	r (One Half of Housing) 2 Supplied	F20-239	90
Cover		F20-240	00
Pump P	ackage Mounting Angle (2 Supplied)	F20-237	70
Dual P	ump Base	F20-243	30
Heater & F	use Kit	1C11290G13	
E-32 Hea	ter (6 Supplied)	E-0860	X
15.0 Amp	Fuse (6 Supplied)	E-2410	X
Instruct	ions (For Heater & Fuse Kit)	1A11252P1	. X
			;
	L PUMP PACKAGE, 1.0 H.P., 200/3/50	D 1N	
Expansion	Tank	P-2840	
Flow Switc	h	P-4620	X
1.0 H.P.,	Dual Pump Package	1D10153G23	
	Pump (2 Supplied)	P-280B	X
Dual Pum	p Housing	1D10118G6	5
Wrappe	r (One Half of Housing) 2 Supplied	F20-239	90
Cover		F20-240	00
Pump P	ackage Mounting Angle (2 Supplied)	F20-237	?O
Dual P	rump Base	F20-243	30
Heater & F	tuse Kit	1C11290G15	
E-44 Hea	ter (6 Supplied)	E-0910	Х
	Fuse (6 Supplied)	E-2070	Х
Instruct	ions (For Heater & Fuse Kit)	1A11252P1	. х

	SECTION II - DUAL PUMP PACKAGE (Continue	ed)	
Find No		Part Number	RSE
	COMPLETE DUAL PUMP PACKAGE, 1.5 H.P., 460/3/60	D 1.5A	
	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	1.5 H.P., Dual Pump Package	1D10153G26	
	1.5 H.P. Pump (2 Supplied)	P-281A	X
	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-2390	)
	Cover	F20-2400	)
	Pump Package Mounting Angle (2 Supplied)	F20-2370	)
	Dual Pump Base	F20-2430	)
	Heater & Fuse Kit	1C11290G3	
	E-34 Heater (6 Supplied)	E-2610	Х
	15.0 Amp Fuse (6 Supplied)	E-2410	
	Instructions (For Heater & Fuse Kit)	1A11252P1	
	COMPLETE DUAL PUMP PACKAGE, 1.5 H.P., 575/3/60	D 1.5B	
	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	1.5 H.P., Dual Pump Package	1D10153G27	
	1.5 H.P. Pump (2 Supplied)	P-281B	X
	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-2390	)
	Cover	F20-2400	)
	Pump Package Mounting Angle (2 Supplied)	F20-2370	)
	Dual Pump Base	F20-2430	
	Heater & Fuse Kit	1C11290G5	
	E-29 Heater (6 Supplied)	E-1840	Х
	15.0 Amp Fuse (6 Supplied)	E-2410	
	Instructions (For Heater & Fuse Kit)	1A11252P1	
	COMPLETE DUAL PUMP PACKAGE, 1.5 H.P., 380/3/50	D 1.5M	
	Expansion Tank	P-2840	
	Flow Switch	P-4620	Х
	1.5 H.P., Dual Pump Package	1D10153G25	
	1.5 H.P. Pump (2 Supplied)	P-280A	Х
	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-2390	)
	Cover	F20-2400	
	Pump Package Mounting Angle (2 Supplied)	F20-2370	
	Dual Pump Base	F20-2430	
	Heater & Fuse Kit	1C11290G24	•
	E-37 Heater (6 Supplied)	E-0870	Х
	15.0 Amp Fuse (6 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	X

	SECTION II - DUAL PUMP PACKAGE (Continu	ed)	
Find No	Description	Part Number	RSP
1	COMPLETE DUAL PUMP PACKAGE, 1.5 H.P., 200/3/50	D 1.5N	
1	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
1	1.5 H.P., Dual Pump Package	1D10153G28	
1	1.5 H.P. Pump (2 Supplied)	P-5070	X
	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-239	0
	Cover	F20-240	0
1	Pump Package Mounting Angle (2 Supplied)	F20-237	0
!	Dual Pump Base	F20-2430	0
1	Heater & Fuse Kit	1C11290G4	
1	E-48 Heater (6 Supplied)	E-0940	X
1	15.0 Amp Fuse (6 Supplied)	E-2070	X
]	Instructions (For Heater & Fuse Kit)	1A11252P1	X
1	COMPLETE DUAL PUMP PACKAGE, 1.5 H.P., 208/3/60	D 1.5Y	
1	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	1.5 H.P., Dual Pump Package	1D10153G26	:
	1.5 H.P. Pump (2 Supplied)	P-281A	y
i	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-239	Ο ,
[	Cover	F20-240	)
i	Pump Package Mounting Angle (2 Supplied)	F20-2370	0
!	Dual Pump Base	F20-2430	9
	Heater & Fuse Kit	1C11290G1	
	E-44 Heater (6 Supplied)	E-0910	X
	15.0 Amp Fuse (6 Supplied)	E-2070	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	X
1	COMPLETE DUAL PUMP PACKAGE, 2.0 H.P., 460/3/60	D 2A	
ĺ	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	2.0 H.P., Dual Pump Package	1D10153G30	
	2.0 H.P. Pump (2 Supplied)	P-381B	X
[	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-2390	C
1	Cover	F20-2400	<b>C</b>
1	Pump Package Mounting Angle (2 Supplied)	F20-2370	o i
ĺ	Dual Pump Base	F20-2430	<b>C</b>
1	Heater & Fuse Kit	1C11290G2	
l	E-38 Heater (6 Supplied)	E-0880	Х
	15.0 Amp Fuse (6 Supplied)	E-2410	Х
	Instructions (For Heater & Fuse Kit)	1A11252P1	

	SECTION II - DUAL PUMP PACKAGE (Continue	ed)	
Find No	Description	Part Number	RSP
	COMPLETE DUAL PUMP PACKAGE, 2.0 H.P., 575/3/60	D 2B	
	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	2.0 H.P., Dual Pump Package	1D10153G31	
	2.0 H.P. Pump (2 Supplied)	P-381C	X
	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-239	0
	Cover	F20-240	0
	Pump Package Mounting Angle (2 Supplied)	F20-237	0
	Dual Pump Base	F20-243	
	Heater & Fuse Kit	1C11290G3	
	E-34 Heater (6 Supplied)	E-2610	Х
	15.0 Amp Fuse (6 Supplied)	E-2410	
	Instructions (For Heater & Fuse Kit)	1A11252P1	
	COMPLETE DUAL PUMP PACKAGE, 2.0 H.P., 380/3/50	D 2M	
	Expansion Tank	P-2840	
	Flow Switch	P-4620	Х
	2.0 H.P., Dual Pump Package	1D10153G29	Λ
	2.0 H.P. Pump (2 Supplied)	P-282A	Х
	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-239	
	Cover	F20-240	
	Pump Package Mounting Angle (2 Supplied)		
	Dual Pump Base		
	Heater & Fuse Kit	F20-243	U
	E-41 Heater (6 Supplied)	1C11290G7	77
	15.0 Amp Fuse (6 Supplied)		X
	Instructions (For Heater & Fuse Kit)	E-2410	
	institutions (For heater & ruse Kit)	1A11252P1	Х
	COMPLETE DUAL PUMP PACKAGE, 2.0 H.P., 200/3/50		
	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	2.0 H.P., Dual Pump Package	1D10153G32	
	2.0 H.P. Pump (2 Supplied)	P-5080	X
	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-239	) C
	Cover	F20-240	o i
	Pump Package Mounting Angle (2 Supplied)	F20-237	כ [
	Dual Pump Base	F20-243	o i
	Heater & Fuse Kit	1C11290G9	
	E-52 Heater (6 Supplied)	E-0960	Х
	15.0 Amp Fuse (6 Supplied)	E-2070	X
******	Instructions (For Heater & Fuse Kit)	1A11252P1	X

	SECTION II - DUAL PUMP PACKAGE (Continue	ed)	!
  Find No	Description	Part Number	RSP
	COMPLETE DUAL PUMP PACKAGE, 2.0 H.P., 208/3/60	D 2Y	:
1	Expansion Tank	P-2840	i
1	Flow Switch	P-4620	X
i S	2.0 H.P., Dual Pump Package	1D10153G30	į
i t	2.0 H.P. Pump (2 Supplied)	P-381B	Х
i,	Dual Pump Housing	1D10118G6	
i	Wrapper (One Half of Housing) 2 Supplied		
	<del></del>	F20-2400	
	Cover		
i	Pump Package Mounting Angle (2 Supplied)	F20-2430	
	Dual Pump Base		'
	Heater & Fuse Kit	1C11290G6	17
	E-49 Heater (6 Supplied)	E-1810	
!	15.0 Amp Fuse (6 Supplied)	E-2070	
	Instructions (For Heater & Fuse Kit)	1A11252P1	Х
•	COMPLETE DUAL PUMP PACKAGE, 3.0 H.P., 460/3/60	D 3A	
• •	Expansion Tank	P-2840	
1	Flow Switch	P-4620	$\Sigma$
1	3.0 H.P., Dual Pump Package	1D10153G34	
	3.0 H.P. Pump (2 Supplied)	P-296A	X
•	Dual Pump Housing	1D10118G6	
•	Wrapper (One Half of Housing) 2 Supplied		)
į	Cover	F20-2400	
ļ	Pump Package Mounting Angle (2 Supplied)		
		F20-2430	
	Dual Pump Base		,
	Heater & Fuse Kit	1C11290G7	47
i	E-41 Heater (6 Supplied)	E-2660	
i	15.0 Amp Fuse (6 Supplied)	E-2410	
	Instructions (For Heater & Fuse Kit)	1A11252P1	X
1	COMPLETE DUAL PUMP PACKAGE, 3.0 H.P., 575/3/60	D 3B	
1	Expansion Tank	P-2840	
i	Flow Switch	P-4620	X
i	3.0 H.P., Dual Pump Package	1D10153G35	
i	3.0 H.P. Pump (2 Supplied)	P-296B	X
!	Dual Pump Housing	1D10118G6	
l I	Wrapper (One Half of Housing) 2 Supplied		
i i	Cover	F20-2400	
i	Pump Package Mounting Angle (2 Supplied)	F20-2370	
i		F20-2430	
i	Dual Pump Base	1C11290G2	_
!	Heater & Fuse Kit	E-0880	v
1	E-38 Heater (6 Supplied)		X
	15.0 Amp Fuse (6 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	<u> </u>

	SECTION II - DUAL PUMP PACKAGE (Continu	ued)	
Find In		Part Number	RSP
	COMPLETE DUAL PUMP PACKAGE, 3.0 H.P., 380/3/50	D 3M	
	Expansion Tank	P-2840	
	Flow Switch	P-4620	$\Sigma$
	3.0 H.P., Dual Pump Package	1D10153G33	
	3.0 H.P. Pump (2 Supplied)	P-285A	X
	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-2390	)
	Cover	F20-2400	)
	Pump Package Mounting Angle (2 Supplied)	F20-2370	)
	Dual Pump Base	F20-2430	)
	Heater & Fuse Kit	1C11290G10	
	E-44 Heater (6 Supplied)	E-0910	Х
	15.0 Amp Fuse (6 Supplied)	E-2410	
	Instructions (For Heater & Fuse Kit)	1A11252P1	
	,		•
	COMPLETE DUAL PUMP PACKAGE, 3.0 H.P., 200/3/50	D 3N	
	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	3.0 H.P., Dual Pump Package	1D10153G36	
	3.0 H.P. Pump (2 Supplied)	P-5090	$\mathbf{X}$
	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-2390	)
	Cover	F20-2400	)
	Pump Package Mounting Angle (2 Supplied)	F20-2370	)
	Dual Pump Base	F20-2430	)
	Heater & Fuse Kit	1C11290G9	
	E-53 Heater (6 Supplied)	E-0970	X
	15.0 Amp Fuse (6 Supplied)	E-2070	Х
	Instructions (For Heater & Fuse Kit)	1A11252P1	
	COMPLETE DIVIN DISCUSOR OF THE COOK OF THE	<b>-</b>	
	COMPLETE DUAL PUMP PACKAGE, 3.0 H.P., 208/3/60		
	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	3.0 H.P., Dual Pump Package	1D10153G34	
	3.0 H.P. Pump (2 Supplied)	P-296A	X
	Dual Pump Housing	1D10118G6	
	Wrapper (One Half of Housing) 2 Supplied	F20-2390	
	Cover	F20-2400	
	Pump Package Mounting Angle (2 Supplied)	F20-2370	)
	Dual Pump Base	F20-2430	)
	Heater & Fuse Kit	1C11290G8	
	E-52 Heater (6 Supplied)	E-0960	Х
	15.0 Amp Fuse (6 Supplied)	E-2070	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	X

	SECTION II - DUAL PUMP PACKAGE (Continue	ed)	
  Find No	Description	Part Number	RSP
[	COMPLETE DUAL PUMP PACKAGE, 5.0 H.P., 460/3/60	D 5A	
	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	5.0 H.P., Dual Pump Package	1D10153G37	
	5.0 H.P. Pump (2 Supplied)	P02-001A	X
1	Dual Pump Housing	1D10118G2	
!	Wrapper (One Half of Housing) 2 Supplied	F20-239	0
1	Cover	F20-240	0
!	Pump Package Mounting Angle (2 Supplied)	F20-237	0
! !	Dual Pump Base	F20-243	0
	Heater & Fuse Kit	1C11290G14	
İ	E-51 Heater (6 Supplied)	E-0950	Х
	15.0 Amp Fuse (6 Supplied)	E-2410	
	Instructions (For Heater & Fuse Kit)		
<u>.</u>	COMPLETE DUAL PUMP PACKAGE, 5.0 H.P., 575/3/60	D 5B	
	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	5.0 H.P., Dual Pump Package	1D10153G38	
	5.0 H.P. Pump (2 Supplied)	P02-001B	
!	Dual Pump Housing	1D10118G2	
	Wrapper (One Half of Housing) 2 Supplied		
	Cover	F20-240	
	Pump Package Mounting Angle (2 Supplied)		
	Dual Pump Base	F20-243	
	Heater & Fuse Kit	1C11290G16	
	E-47 Heater (6 Supplied)	E-0930	Х
	15.0 Amp Fuse (6 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)		
	COMPLETE DUAL PUMP PACKAGE, 5.0 H.P., 208/3/60	D 5Y	
	Expansion Tank	P-2840	
	Flow Switch	P-4620	X
	5.0 H.P., Dual Pump Package	1D10153G37	
	5.0 H.P. Pump (2 Supplied)	P02-001A	X
	Dual Pump Housing	1D10118G2	
	Wrapper (One Half of Housing) 2 Supplied	F20-239	
	Cover	F20-240	
	Pump Package Mounting Angle (2 Supplied)	F20-237	
	Dual Pump Base	F20-243	
	Heater & Fuse Kit	1C11290G7	~
	E-60 Heater (6 Supplied)	E-2670	Х
	25.0 Amp Fuse (6 Supplied)	E-2080	X
ı	Instructions (For Heater & Fuse Kit)	1A11252P1	

	SECTION I - SINGLE PUMP PACKAGE		
  Find No		art Number	RSP
1	COMPLETE PUMP PACKAGE, 1.5 H.P., 208/3/60	018-1625	
	3-WAY Valve	P-0310	X
	Compression Tank	P-4740	
1	Relief Valve	P-4730	
İ	Modulating Motor	M-0020	X
;	Linkage	M-0050	X
1	Single Pump Package	S1-1/2YNT	
İ	1.5 H.P., Single Pump Package	1D10153G8	
	1.5 H.P. Pump	P-281A	X
• •	Single Pump Housing	1D10118G8	3
	Wrapper (One Half of Housing) 2 Supplied Cover	F20-235 F20-236	
: !	Pump Package Mounting Angle (2 Supplied)		
i i	Single Pump Base	F20-244	
į	Heater & Fuse Kit	1C11288G1	
<u> </u>	E-44 Heater (3 Supplied)	E-0910	
: !	15.0 Amp Fuse (3 Supplied)	E-2070	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	
*	COMPLETE PUMP PACKAGE, 1.5 H.P., 460/3/60	018-1626	
	3-WAY Valve	P-0310	X
	Compression Tank	P-4740	
•	Relief Valve	P-4730	
· · · · · · · · · · · · · · · · · · ·	Modulating Motor	M-0020	Х
F I	Linkage	M-0050	X
•	Single Pump Package	S1-1/2ANT	
•	1.5 H.P., Single Pump Package	1D10153G8	
F T 1 2	1.5 H.P. Pump	P-281A	Х
İ	Single Pump Housing	1D10118G8	3
	Wrapper (One Half of Housing) 2 Supplied		
•	Cover	F20-236	_
1	Pump Package Mounting Angle (2 Supplied)		-
	Single Pump Base	F20-244	
	Heater & Fuse Kit	1C11288G3	
•	E-34 Heater (3 Supplied)	E-2610	
	15.0 Amp Fuse (3 Supplied)	E-2410	Х
I	Instructions (For Heater & Fuse Kit)	1A11252P1	

	SECTION I - SINGLE PUMP PACKAGE (Continu	ued)	
Find No		Part Number	RSP
	COMPLETE PUMP PACKAGE, 1.5 H.P., 575/3/60	018-1627	
	3-WAY Valve	P-0310	X
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	X
	Linkage	M-0050	X
	Single Pump Package	S1-1/2BNT	
	1.5 H.P., Single Pump Package	1D10153G9	
	1.5 H.P. Pump	P-281B	X
	Single Pump Housing	1D10118G8	ŝ
	Wrapper (One Half of Housing) 2 Supplied Cover	F20-235 F20-236	
	Pump Package Mounting Angle (2 Supplied)	F20-237	0
	Single Pump Base	F20-244	
	Heater & Fuse Kit	1C11288G5	-
	E-29 Heater (3 Supplied)	E-1840	
	15.0 Amp Fuse (3 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	
	COMPLETE PUMP PACKAGE, 2.0 H.P., 208/3/60	018-1628	
	3-WAY Valve	P-0310	X
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	Х
	Linkage	M-0050	X
	Single Pump Package	S2YNT	
	2.0 H.P., Single Pump Package	1D10153G12	
	2.0 H.P. Pump	P-381B	Х
	Single Pump Housing	1D10118G8	}
	Wrapper (One Half of Housing) 2 Supplied		
	Cover	F20-236	
	Pump Package Mounting Angle (2 Supplied)		_
	Single Pump Base	F20-244	_
	Heater & Fuse Kit	1C11288G6	
	E-49 Heater (3 Supplied)	E-1810	
	15.0 Amp Fuse (3 Supplied)	E-2070	Х
	Instructions (For Heater & Fuse Kit)	1A11252P1	

	SECTION I - SINGLE PUMP PACKAGE (Contin	ued)	
Find No		Part Number	RSP
	COMPLETE PUMP PACKAGE, 2.0 H.P., 460/3/60	018-1629	
	3-WAY Valve	P-0310	X
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	X
	Linkage	M-0050	X
	2.0 H.P., Single Pump Package	1D10153G12	
	2.0 H.P. Pump	P-381B	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-2350	
	Cover	F20-2360	
	Pump Package Mounting Angle (2 Supplied)	F20-2370	
	Single Pump Base	F20-2440	
	Heater & Fuse Kit	1C11288G2	
	E-38 Heater (3 Supplied)	E-0880	
	15.0 Amp Fuse (3 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	Х
	COMPLETE PUMP PACKAGE, 2.0 H.P., 575/3/60	018-1630	
	3-WAY Valve	P-0310	Х
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	Х
	Linkage	M-0050	Х
	Single Pump Package	S2BNT	
	2.0 H.P., Single Pump Package	1D10153G13	
	2.0 H.P. Pump	P-381C	Х
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplie		o i
	Cover	F20-2360	- O
	Pump Package Mounting Angle (2 Supplied		- 1
	Single Pump Base	F20-2440	•
	Heater & Fuse Kit	1C11288G3	- i
	E-34 Heater (3 Supplied)	E-2610	
	15.0 Amp Fuse (3 Supplied)	E-2410	х
	Instructions (For Heater & Fuse Kit)	1A11252P1	

Find No	Description		
		art Number	RSP
	COMPLETE PUMP PACKAGE, 2.0 H.P., 208/3/60	018-1631	
!	3-WAY Valve	P-3600	X
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	X
	Linkage	M-0050	X
i	Single Pump Package	S2YNT	
i	2.0 H.P., Single Pump Package	1D10153G12	
· I	2.0 H.P. Pump	P-381B	Х
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-2350	0
	Cover	F20-2360	0
	Pump Package Mounting Angle (2 Supplied)	F20-2370	0
	Single Pump Base	F20-2440	0
	Heater & Fuse Kit	1C11288G6	
	E-49 Heater (3 Supplied)	E-1810	
(	15.0 Amp Fuse (3 Supplied)	E-2070	Х
I	Instructions (For Heater & Fuse Kit)	1A11252P1	
	COMPLETE PUMP PACKAGE, 2.0 H.P., 460/3/60	018-1632	
	3-WAY Valve	P-3600	Х
	Compression Tank	P-4740	••
	Relief Valve	P-4730	
	Modulating Motor	M-0020	х
	Linkage	M-0050	X
	2.0 H.P., Single Pump Package	1D10153G12	71
	2.0 H.P. Pump	P-381B	X
	Single Pump Housing	1D10118G8	4.
	Wrapper (One Half of Housing) 2 Supplied	F20-2350	
	Cover	F20-2350 F20-2360	
	Pump Package Mounting Angle (2 Supplied)	F20-2370	1
	Single Pump Base	F20-2310	i
	Heater & Fuse Kit	1C11288G2	
	E-38 Heater (3 Supplied)	E-0880	
	15.0 Amp Fuse (3 Supplied)	E-0880 E-2410	v
	Instructions (For Heater & Fuse Kit)	1A11252P1	X

	SECTION I - SINGLE PUMP PACKAGE (Continu	ied)	
Find No	Description F	Part Number	RSP
	COMPLETE PUMP PACKAGE, 2.0 H.P., 575/3/60	018-1633	
	3-WAY Valve	P-3600	X
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	X
	Linkage	M-0050	X
	Single Pump Package	S2BNT	
	2.0 H.P., Single Pump Package	1D10153G13	
	2.0 H.P. Pump	P-381C	X
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-235	0
	Cover	F20-236	0
	Pump Package Mounting Angle (2 Supplied)	F20-237	0
	Single Pump Base	F20-244	0
	Heater & Fuse Kit	1C11288G3	
	E-34 Heater (3 Supplied)	E-2610	
	15.0 Amp Fuse (3 Supplied)	E-2410	Х
	Instructions (For Heater & Fuse Kit)	1A11252P1	X
	COMPLETE PUMP PACKAGE, 1.0 H.P., 200/3/50	018-1634	
	3-WAY Valve	P-0310	Х
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	Х
	Linkage	M-0050	X
	Single Pump Package	S1NNT	
	1.0 H.P., Single Pump Package	1D10153G5	
	1.0 H.P. Pump	P-280B	Х
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied	F20-235	0
	Cover	F20-236	0
	Pump Package Mounting Angle (2 Supplied)		_
	Single Pump Base	F20-244	_
	Heater & Fuse Kit	1C11288G15	
	E-44 Heater (3 Supplied)	E-0910	X
	15.0 Amp Fuse (3 Supplied)	E-2070	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	

_	SECTION I - SINGLE PUMP PACKAGE (Continu	led)	
Find No		art Number	RSE
	COMPLETE PUMP PACKAGE, 1.0 H.P., 400/3/50	018-1635	
	3-WAY Valve	P-0310	X
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	X
	Linkage	M-0050	X
	Single Pump Package	SIMVT	
	1.0 H.P., Single Pump Package	1D10153G5	
	1.0 H.P. Pump	P-280B	X
	Single Pump Housing	1D10118G8	3
	Wrapper (One Half of Housing) 2 Supplied Cover	F20-235 F20-236	
	Pump Package Mounting Angle (2 Supplied)		
	Single Pump Base	F20-244	
	Heater & Fuse Kit	1C11288G13	ro
	E-32 Heater (3 Supplied)	E-0860	Х
	15.0 Amp Fuse (3 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	
	COMPLETE PUMP PACKAGE, 1.5 H.P., 200/3/50	018-1636	
	3-WAY Valve	P-0310	Х
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	Х
	Linkage	M-0050	Y
	Single Pump Package	S1-1/2NNT	
	1.5 H.P., Single Pump Package	1D10153G10	
	1.5 H.P. Pump	P-5070	Х
	Single Pump Housing	1D10118G8	
	Wrapper (One Half of Housing) 2 Supplied		
	Cover	F20-236	
	Pump Package Mounting Angle (2 Supplied)		-
	Single Pump Base	F20-244	-
	Heater & Fuse Kit	1C11288G4	
	E-48 Heater (3 Supplied)	E-0940	Х
	15.0 Amp Fuse (3 Supplied)	E-2070	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	

	SECTION I - SINGLE PUMP PACKAGE (Continu	ed)	
  Find No		art Number	RSP
	COMPLETE PUMP PACKAGE, 1.5 H.P., 380/3/50	018-1637	
1	3-WAY Valve	P-0310	X
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	X
	Linkage	M-0050	X
[	Single Pump Package	S1-1/2MNT	
İ	1.5 H.P., Single Pump Package	1D10153G7	
	1.5 H.P. Pump	P-280A	Я
	Single Pump Housing	1D10118G8	}
i	Wrapper (One Half of Housing) 2 Supplied	F20-235	50
[	Cover	F20-236	SO
	Pump Package Mounting Angle (2 Supplied)	F20-237	0
	Single Pump Base	F20-244	10
	Heater & Fuse Kit	1C11288G24	
	E-37 Heater (3 Supplied)	E-0870	X
	15.0 Amp Fuse (3 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	. Х
	COMPLETE PUMP PACKAGE, 2.0 H.P., 200/3/50	018-1638	
	3-WAY Valve	P-3600	X
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	X
	Linkage	M-0050	X
	Single Pump Package	S2NNT	
	2.0 H.P., Single Pump Package	1D10153G14	
	2.0 H.P. Pump	P-5080	X
	Single Pump Housing	1D10118G8	3
	Wrapper (One Half of Housing) 2 Supplied	F20-235	50
	Cover	F20-236	50
: !	Pump Package Mounting Angle (2 Supplied)	F20-237	70
	Single Pump Base	F20-244	10
	Heater & Fuse Kit	1C11288G9	
	E-52 Heater (3 Supplied)	E-0960	X
	15.0 Amp Fuse (3 Supplied)	E-2070	X
	Instructions (For Heater & Fuse Kit)	1A11252P1	

	SECTION I - SINGLE PUMP PACKAGE (Conti	inued)	
Find No	Description	Part Number	RSP
	COMPLETE PUMP PACKAGE, 2.0 H.P., 380/3/50	018-1639	
	3-WAY Valve	P-3600	X
	Compression Tank	P-4740	
	Relief Valve	P-4730	
	Modulating Motor	M-0020	X
	Linkage	M-0050	Х
	Single Pump Package	S2MNT	
	2.0 H.P., Single Pump Package	1D10153G11	
	2.0 H.P. Pump	P-282A	X
	Single Pump Housing	1D10118G	8
	Wrapper (One Half of Housing) 2 Suppli	ied F20-23	350
	Cover	F20-23	360
	Pump Package Mounting Angle (2 Supplie	ed) F20−23	370
	Single Pump Base	F20-24	40
	Heater & Fuse Kit	1C11288G7	
	E-41 Heater (3 Supplied)	E-2660	Х
	15.0 Amp Fuse (3 Supplied)	E-2410	X
	Instructions (For Heater & Fuse Kit)	1A11252P	21 X

#### APPENDIX G (Continued)

# PUMP PACKAGES FOR LIEBERT DRYCOOLERS SELECTIONS (Continued) CHILLER SERIES 3000 GLYCOOL MODELS

MODEL NUMBER	HERTZ	VOLTAGE	STANDARD H.P.	OPTIONAL H.P.	PUMP PACKAGE !
AS-53G	50	200	1.0		018-1634
CS-27G	50	230	1.0		018-1634
CD-54G**	50	380	1.0	1	018-1635
AS-63G	60	208	1.5	[	018-1625
CS-32G	60	208		2.0	018-1628
CD-64G**	60	460	1.5		018-1626
	<b>6</b> C	460		2.0	018-1629
	60	575	1.5		018-1627
	<b>6</b> 0	575		2.0	018-1630
AS-89G	50	200	1.5		018-1636
CS-45G	50	230	1.5		018-1636
CD-90G**	50	380	1.5		018-1637
AS-103G	60	208	1.5	1	018-1625
CS-52G	60	208		2.0	018-1628
CD-104G**	60	460	1.5		018-1626
Ī	60	460		2.0	018-1629
Ī	60	575	1.5		018-1627
	60	575		2.0	018-1630
AS-167G	50	200	2.0		018-1638
CS-84G	50	230	2.0		018-1638
CD-168G**	50	380	2.0	 	018-1639
AS-1690	60	208	2.0	 	018-1631
CS-85G	60	460	2.0		018-1632
CD-170G**	60	575	2.0		018-1633
AS-203G	60	208	2.0		018-1631
CS-102G	60	460	2.0		018-1632
CD-204G**	60	575	2.0		018-1633
AS-211G	50	200	2.0		018-1638
CS-106G	50	230	2.0		018-1638
CD-212G**	50	380	2.0		018-1639
AS-251G	60	208	2.0		018-1631
CS-126G	60	460	2.0		018-1632
CD-252G**	60	575	2.0		018-1633

<sup>\*\*</sup> MODELS WITH A "CD" PREFIX REQUIRE TWO (2) COMPLETE PUMP PACKAGES.

#### APPENDIX G

## PUMP PACKAGES FOR LIEBERT DRYCOOLERS SELECTIONS CHALLENGER II/SYSTEM III/CHILLER SERIES 3000 GLYCOL MODELS

MODEL NUMBER	HERTZ	VOLTAGE	HORSEPOWER	PUMP PACKAGE
CF/CU 41G	50	200	.75	S 3/4W
CF/CU 41G	60	208	.75	S 3/42*
CF/CU 60G	50	200	.75	S 3/4W
CF/CU 60G	60	208	.75	S 3/4P*
FH/UH 72G	50	200	1.5	* 1.5N
FH/UH 72G	50	380	1.5	* 1.5M
FH/UH 72G	60	208	1.5	* 1.5Y
FH/UH 72G	60	460	1.5	* 1.5A
FH/UH 72G	60	575	1.5	* 1.5B
FH/UH 111G	50	200	1.5	* 1.5N
FH/UH 111G	50	380	1.5	* 1.5M
FH/UH 110G	60	208	1.5	* 1.5Y
FH/UH 110G	. 6C	460	1.5	* 1.5A
FH/UH 110G	60	575	1.5	* 1.5B
FH/UH 116G	60	208	1.5	* 1.5Y
FH/UH 116G	60	460	1.5	* 1.5A
FH/UH 116G	60	575	1.5	* 1.5B
FH/UH 121G	50	200	1.5	* 1.5N
FH/UH 121G	50	380	1.5	* 1.5M
FH/UH 192G	50	200	2.0	* 2.0N
FH/UH 192G	50	380	2.0	* 2.0M
FH/UH 192G	1 60	208	2.0	* 2.0Y
FH/UH 192G	60	460	2.0	* 2.0A
FH/UH 192G	60	575	2.0	* 2.0B
FH/UH 240G	1 50	200	3.0	* 3.0N
FH/UH 240G	50	380	3.0	* 3.0M
FH/UH 240G	60	208	3.0	* 3.0Y
FH/UH 240G	60	460	3.0	* 3.0A
FH/UH 240G	60	575	3.0	* 3.0B
FH/UH 265G	50	200	3.0	* 3.0N
FH/UH 265G	50	380	3.0	* 3.0M
FH/UH 265G	60	208	3.0	* 3.0Y
FH/UH 265G	60	460	3.0	* 3.0A
FH/UH 265G	60	575	3.0	* 3.0B
AS-53G	1 50	200	1.0	* 1.0N
CS-27G	50	230	1.0	* 1.0M
CD-54G** .	1		1	
AS-89G				
CS-45G	Ī			
CD-90G**	1	<u> </u>		1
ALL OTHER	50	200	1.5	* 1.5N
CHILLERS**	50	380	1.5	* 1.5M
	60	208	1.5	* 1.5Y
	60	460	1.5	* 1.5A
	60	575	1.5	* 1.5B

<sup>\*</sup> DUAL .75 H.P. PUMP PACKAGES HAVE A MODEL NUMBER OF D .75P

<sup>\*\*</sup> MODELS WITH A "CD" PREFIX REQUIRE TWO (2) COMPLETE PUMP PACKAGES.

#### APPENDIX G

# PUMP PACKAGES FOR LIEBERT DRYCOOLERS SELECTIONS SYSTEM III GLYCOOL MODELS

MODEL NUMBER	HERTZ	VOLTAGE	HORSEPOWER	PUMP PACKAGE
FE/UE 72G	50	200	1.5	* 1.5N
FE/UE 72G	50	380	1.5	* 1.5M
FE/UE 72G	<u> </u> 60	208	1.5	* 1.5Y
FE/UE 72G	60	460	1.5	* 1.5A
FE/UE 72G	60	575	1.5	* 1.5B
FE/UE 111G	50	200	1.5	* 1.5N
FE/UE 111G	50	380	1.5	* 1.5M
FE/UE 110G	. 60	208	1.5	* 1.5Y
FE/UE 110G	J 60	460	1.5	* 1.5A
FE/UE 110G	60	<b>57</b> 5	1.5	* 1.58
FE/UE 116G	60	208	2.0	* 2.0Y
FE/UE 116G	[ 60	460	2.0	* 2.0A
FE/UE 116G	60	<b>57</b> 5	2.0	* 2.03
FE/UE 121G	50	200	1.5	* 1.5N
FE/UE 121G	50	380	1.5	* 1.5M
FE/UE 192G	50	200	2.0	* 2.0N
FE/UE 192G	50	380	2.0	* 2.0M
FE/UE 192G	60	208	3.0	* 3.0Y
FE/UE 192G	60	460	3.0	* 3.0A
FE/UE 192G	[ 60	575	3.0	* 3.0B
FE/UE 240G	50	200	3.0	* 3.0N
FE/UE 240G	50	380	3.0	* 3.0M
FE/UE 240G	60	208	3.0	* 3.0Y
FE/UE 240G	60	460	3.0	* 3.0A
FE/UE 240G	60	575	3.0	* 3.0B