

Little Glass House LGH 1000 Parts Manual Rev. 11/93

Liebert Corporation may make improvements and/or changes in the products described in the document at any time without notice. Part numbers and technical information are subject to change without prior notice.

Liebert Corporation assumes no responsibility and disclaims all liability for incidental or consequential damages resulting for use of this information from errors or omissions.



Parts Manual

			,
			, while ,
			-
			- i
			- : 2
			- Z
			- / / / / / / / / / / / / / / / / / / /
			- / / / / / / / / / / / / / / / / / / /
			- /- /- /- /- /- /- /- /- /- /- /- /- /-

Little Glass House LGH 1000 Parts Manual

November 1993

Disclaimer of Warranties and Limitation of Liabilities

The authors and editors have taken every precaution to ensure accuracy and completeness in this manual. The authors and editors make no expressed or implied warranty of any kind with regard to the documentation in this manual. Liebert Corporation assumes no responsibility, and disclaims all liability for incidental or consequential damages resulting from the use of this information or from errors or omissions. Liebert Corporation may make improvements and/or changes in the product(s) described in this manual at any time. Information in this manual is subject to change at any time and does not represent a commitment on the part of Liebert Corporation.

A Reader Comment Form is at the back of this manual. If the form is not there, address comments to: Liebert Corporation, Customer Service & Support Division, 250 East Wilson Bridge Road, Suite 100, CS&S Documentation Department, Worthington, OH 43085. Liebert Corporation may use or distribute the information you supply in any way it believes appropriate without incurring any obligation whatever.

Liebert® and the Liebert logo are registered trademarks of Liebert Corporation.


Copyright © 1993 by Liebert Corporation All rights reserved

Printed in the United States of America

Table of Contents

Find 1	Number (FN)	Page
	How to Use This Manual	iv
1	Frame Assembly	3
2	Cord/Receptacle Assembly	4
3	Damper/Filter Assembly, Front	4
4	Door Assemblies	7
5	Module Assemblies	7
6	Options	8
	Reader Comment Form	

How to Use This Manual




six major parts sections as listed in the Table of Contents. Each section applies to a group of related parts or to a major assembly.


The Little Glass House Parts Manual is made up of

a Find Number is a sequentially-assigned two-part number. The FN matches a picture of a part to the part number and description in each table. The first part of the FN is the table number. The second part is the assembly or component number found sequentially in the table.

Little Glass House



Front View (Front Grille and Air Filter Removed)



Rear View

1 Frame Assembly


FN	Description	Part Number	
1-1	Chassis Guide (UPS "L" Bracket)	138302P1	
1-2	Caster	138256P1	
1-3	Channel, Rack Mounting	138298P1	
1-4	Rack Mount Channel	138297P1	
1-5	Shelf, Internal	138815P1	
1-6	Front Grille	138793P1	
1-7	Leveler Foot	138300P1	
1-8	Hinge Bracket	138291P2	
1-9	Hinge Pin	138291P3	
1-10	Gasket	138320P1	
1-11	Collar/Panel Assembly	138294G1	
1-12	Panel, Wire Exit/Entrance	138307P1	
1-13	Thermostat (SPST, 90°F)	138776P1	
1-14	Bracket, Thermostat	138975P1	
1-15	Cover, Thermostat	138823P1	
1-16	Panel, Left Side	138193P2	
1-17	Panel, Right Side	138193P1	
1-18	Angle Panel Mount, Rear	138206P1	
1-19	Plug and Molding Strip	138271P1	
1-20	Plug Mold Connector	138272P1	
1-21	Wireway Assembly	139053G1	

2 Cord/Receptacle Assembly


FN	Description	Part Number
2-1	Cord/Receptacle Assembly, 20 Amp	138799G1
2-2	Line Cord, 14/3, 2 ft.	138784P1
2-3	Plug, 20 Amp, 125 Volt, NEMA 5-20P	138782P1
2-4	Socket, Duplex, 20 Amp, 125 Volt	138783P1
2-5	Plate, Duplex Mounting	138794P1
2-6	Terminal Strip Section (1 Position)	E-0380
2-7	Terminal Strip Section End	E-0390
2-8	Line Cord, 12/3, 10 ft.	138781P1
2-9	Electrical Box	E12-7000
2-10	Electrical Box Cover	E12-1870

3 Damper/Filter Assembly, Front

FN	Description	Part Number	
3-1	Damper/Filter Assembly, Front	138281G1	
3-2	Damper Door	138326P1	
3-3	Valve Solenoid	138788P1	
3-4	Bracket, Front Solenoid	138800P1	
3-5	Relay (Single Pole, NO, 120 VAC)	138777P1	
3-6	Relay (Three Second Delay, 120 VAC)	138773P1	
3-7	Audible Alarm (120 VAC)	138779P1	
3-8	Switch, Air Differential	138787P1	
3-9	Air Filter, 3/8" × 9" × 16"	138308P1	
3-10	Magnetic Gasket, Front	138811P1	



Damper/Filter Assembly, Front (FN 3-1)




Damper/Filter Assembly (Inside Detail)


4 Door Assemblies

FN	Description	Part Number
4-1	Door Assembly, Rear	138314G1
4-2	Door, Rear	138289G1
4-3	Latch Assembly, Rear	138313G1
4-4	Line Cord and Connector	138850G1
4-5	Finger Guard, 6"	516703P1
4-6	Fan (240 CFM, 115 Volt)	5C10877P1
4-7	Damper, Rear Door	138279P1
4-8	Valve Solenoid	138321P1
4-9	Magnetic Gasket, Rear	138812P1
1-10	Door Assembly, Front	138311G1
l-11	Door Weldment, Front	138288G1
4-12	Plexiglass	138301P1
4-13	Latch Assembly, Front	138310G1
4-14	Plexiglass Frame	139012G1

5 Module Assemblies

FN	Description	Part Number	
5-1	Environmental Cooling Module (ECM)	138317G1	
5-2	UPS Module, 1,000 VA, 60 HZ	AU1000RE-60HZ	






UPS Module (FN 5-2)

Environmental Cooling Module (ECM) (FN 5-1)

6 Options

FN	Description	Part Number
6-1	Shelf Kit	KIT-3000
6-2	Chassis Guide Kit ("L" Brackets)	KIT-3001
6-3	Cluster Kit	KIT-3004
6-4	Pull-Out Shelf Kit	KIT-3002
6-5	Slide Rails Kit	KIT-3003
6-6	Heat Rejection Kit	KIT-3005



A Cluster Kit links two units together (FN 6-3)

Reader Comment Form

This manual is a part of a library that serves as a source for suppliers and users of Liebert equipment. The authors have taken every precaution to ensure accuracy and completeness of the manual. Use this form to communicate your views about the publication. Your voluntary input is appreciated.

Mail comments to the address below. All appropriate comments go to the author's department for review and action. You may write comments in your own language. English is not required.

Liebert Corporation
Customer Services & Support Division
250 East Wilson Bridge Road
Suite 100, CS&S Documentation Department
Worthington, OH 43085
614-841-6400

Liebert Corporation may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation whatever. You may, of course, continue to use the information you supply.

	Check if you	wish a reply	to your co	mments.		
	Name: Address:					
	Occupation:					
Comn	nents:					

		:





CUSTOMER SERVICE 4 SUPPORT DIVISION LIEBERT CORPORATION SUBSIDIARY OF EMERSON ELECTRIC CO.

Printed in the U.S.A.

© Liebert and the Liebert logo are registered trademarks of Liebert Corporation.

Appendix P

Parts Manual

ECM42E	P-2
ECM62E	P-3
ECM80E	P-4
UAS 50HZ	P-5
FAC 50HZ	P-6
Front Vent box Assy 50HZ	P-7
Common Parts 50HZ	P-8
ECM42	P-9
ECM62	P-10
ECM80	P-11
UAS 60HZ	P-12
FAC 60HZ	P-13
Front Vent Box Assy 60HZ	P-14
Common Parts 60HZ	P-15

